

LIVEN XFM PRESET SOUND LIST

Category	BANK Name	No.	Name	Note	Category	BANK Name	No.	Name	Note
XFM	XFM1 (BANK1)	1	WGGL	Wiggle Lead	LEAD	LD1 (BANK3)	1	WGGL	Wiggle Lead
		2	ORG.1	Organ 1			2	S.SAW	Super Saw Lead
		3	F.TRP	Forte Trumpet			3	BR.LD	Bright Lead
		4	PSYC	Psychedelica			4	AT.LD	Attacky Lead
		5	DIG.B	Digital Bass			5	PENT	Penta Lead
		6	S.SAW	Super Saw			6	NM.LD	Normal Lead
		7	EP.1	Electric Piano 1			7	PD.LD	Prodigy Lead
		8	DSTR	Distorted Pad			8	SYNC	Sync Lead
		9	ENS1	String Ensemble 1			9	S.SQR	Super Square Lead
		10	DMSR	IDM Sitar			10	BITE	Bity Lead
		11	B.TRP	Bright Trumpet			11	MVOX	Male Voice
		12	FL.BS	Flanging Bass			12	4SAW	4 Bit Saw
		13	S.MAJ	Strummed Major			13	MT.LD	Motion Lead
		14	CRYS	The Crystal			14	MD.LD	Modulated Lead
		15	ORRO	FM Riser			15	UN.LD	Unison Lead
		16	CRWL	Crawl Noise			16	BP.LD	Beep Lead
		XFM2 (BANK2)	1	L.KCK		Low Kick	1	LF.LD	Lo-Fi Lead
			2	H.KCK		Hard Kick	2	S.LD.1	Sweep Lead 1
			3	N.SNR		Normal Snare	3	S.LD.2	Sweep Lead 2
			4	M.SNR		Melodic Snare	4	HP.LD	High Pass Lead
			5	CLP1		Dry Clap 1	5	D.LD	Distorted Lead
			6	NM.HH		Normal Hi Hat	6	N.LD.1	Noisy Lead 1
			7	M.HAT		Metallic Hi Hat	7	N.LD.2	Noisy Lead 2
			8	CRSH		Crash Cymbal	8	CL.LD	Cloudy Lead
			9	M.RID		Metalic Ride	9	VCDR	Vocoder
			10	MLT.D		Multi Drum	10	NES	NES
			11	CWB.1		Cowbell 1	11	PV.LD	PV LEAD
			12	TOM.1		Tom 1	12		
			13	MRMB		Marimba	13		
			14	CHIM		Chime	14		
			15	BUNS		Bouncing Bell	15		
			16	R.YTM		The Rhythmica	16		

Category	BANK Name	No.	Name	Note	Category	BANK Name	No.	Name	Note	
KEYS	KEY1 (BANK5)	1	EP.1	Electric Piano 1	PAD	PAD1 (BANK7)	1	DSTR	Distorted Pad	
		2	EP.2	Electric Piano 2			2	T.GAP	TimeGap Pad	
		3	EP.3	Electric Piano 3			3	D.SAW	Deep Saw Pad	
		4	WD.EP	Wood EP			4	VOXS	Voices Pad	
		5	BEL.P	Bell Piano			5	FOGY	Foggy Pad	
		6	DL.KY	Delayed Keys			6	NZ.PD	Noisy Pad	
		7	AMVE	Ambient Wave			7	NTEL	Nostalgic Bell	
		8	CCOR	Accordion			8	GLAS	Glassy Pad	
		9	PSYC	Psychedelica			9	DK.PD	Dark Pad	
		10	PC.OR	Percussive Organ			10	D.PD.1	Detuned Pad 1	
		11	ORG.1	Organ 1			11	D.PD.2	Detuned Pad 2	
		12	ORG.2	Organ 2			12	D.PD.3	Detuned Pad 3	
		13	ORG.3	Organ 3			13	B.SAW	Bright Saw Pad	
		14	ORG.4	Organ 4			14	BR.PD	Bright Pad	
		15	P.OG.1	Pipe Organ 1			15	C.PAD	Cat'N'Pad	
		16	P.OG.2	Pipe Organ 2			16	SW.PD	Sweep Pad 1	
		KEY2 (BANK6)	1	KEY.1		Keys 1	PAD2 (BANK8)	1	A.PD.1	Attack Pad 1
			2	KEY.2		Keys 2		2	A.PD.2	Attack Pad 2
			3	KEY.3		Keys 3		3	A.PD.3	Attack Pad 3
			4	KEY.4		Keys 4		4	A.PD.4	Attack Pad 4
			5	KEY.5		Keys 5		5	W.PD.1	Warm Pad 1
			6	KEY.6		Keys 6		6	W.PD.2	Warm Pad 2
			7	KEY.7		Keys 7		7	SFT.1	Soft Pad 1
			8	KEY.8		Keys 8		8	SFT.2	Soft Pad 2
			9	KEY.9		Keys 9		9	SFT.3	Soft Pad 3
			10					10	WN.PD	White Noise Pad
			11					11	CHOR	Choir
			12					12	SL.PD	Slow Pad
			13					13		
			14					14		
			15					15		
			16					16		

Category	BANK Name	No.	Name	Note	Category	BANK Name	No.	Name	Note	
STRINGS	STR1 (BANK9)	1	ENS1	String Ensemble 1	WIND	WND1 (BANK11)	1	F.TRP	Forte Trumpet	
		2	ENS2	String Ensemble 2			2	B.TRP	Bright Trumpet	
		3	DMSR	IDM Sitar			3	WD.WN	Woodwind	
		4	GR.ST	Grid Strings			4	FNFR	Fanfare	
		5	VL.1	Violin 1			5	BR.WD	Brassy Wind	
		6	VL.2	Violin 2			6	D.BR.1	Detuned Brass 1	
		7	VLA	Viola			7	D.BR.2	Detuned Brass 2	
		8	VLC.1	Cello 1			8	TRB.1	Trombone 1	
		9	VLC.2	Cello 2			9	TRB.2	Trombone 2	
		10	C.BS	Contra Bass			10	CLRN	Clarinet	
		11	N.ST.1	Noisy Strings 1			11	FLT.1	Flute 1	
		12	N.ST.2	Noisy Strings 2			12	FLT.2	Flute 2	
		13	N.ST.3	Noisy Strings 3			13	TR.FL	Tron-flute	
		14	N.ST.4	Noisy Strings 4			14	RCDR	Recorder	
		15	HRP.1	Harp 1			15	PCCL	Piccolo	
		16	HRP.2	Harp 2			16	WHSL	Whistling	
		STR2 (BANK10)	1	GT.1		Guitar 1	WND2 (BANK12)	1	BR.1	Brass 1
			2	GT.2		Guitar 2		2	BR.2	Brass 2
			3	GT.3		Guitar 3		3	BR.3	Brass 3
			4	GT.4		Guitar 4		4	BR.4	Brass 4
			5	GT.5		Guitar 5		5	BR.5	Brass 5
			6	GT.6		Guitar 6		6	BR.6	Brass 6
			7	D.GT		Distorted Guitar		7	BR.7	Brass 7
			8	M.GT		Mute Guitar		8	BR.8	Brass 8
			9	KOTO		Koto		9	BR.9	Brass 9
			10	SITR		Sitar		10		
			11					11		
			12					12		
			13					13		
			14					14		
			15					15		
			16					16		

Category	BANK Name	No.	Name	Note	Category	BANK Name	No.	Name	Note
BASS	BS1 (BANK13)	1	FL.BS	Flanging Bass	KICK	KCK1 (BANK15)	1	L.KCK	Low Kick
		2	DIG.B	Digital Bass			2	H.KCK	Hard Kick
		3	ALS.B	Alias Bass			3	0908	909 / 808
		4	PUL.B	Pulse Bass			4	DP.KC	Deep Kick
		5	SYN.B	Sync Bass			5	KC.01	Kick 1
		6	HAU.B	Haunting Bass			6	KC.02	Kick 2
		7	DOPL	Doppler Bass			7	KC.03	Kick 3
		8	3BBS	EBM BASS			8	KC.04	Kick 4
		9	OCT.B	Octave Bass			9	KC.05	Kick 5
		10	SWL.B	Swelling Bass			10	KC.06	Kick 6
		11	KCK.B	Kick Bass			11	KC.07	Kick 7
		12	BR.BS	Bright Bass			12	KC.08	Kick 8
		13	E.BS	Electric Bass			13	KC.09	Kick 9
		14	FT.BS	Filtered Bass			14	KC.10	Kick 10
		15	WB.BS	Wobble Bass			15	KC.11	Kick 11
		16	BARK	Barking Bass			16	KC.12	Kick 12
		BS2 (BANK14)	1	BS.01		Bass 1	1	KC.13	Kick 13
			2	BS.02		Bass 2	2	KC.14	Kick 14
			3	BS.03		Bass 3	3	KC.15	Kick 15
			4	BS.04		Bass 4	4		
			5	BS.05		Bass 5	5		
			6	BS.06		Bass 6	6		
			7	BS.07		Bass 7	7		
			8	BS.08		Bass 8	8		
			9	BS.09		Bass 9	9		
			10	BS.10		Bass 10	10		
			11	BS.11		Bass 11	11		
			12	BS.12		Bass 12	12		
			13	BS.13		Bass 13	13		
			14	BS.14		Bass 14	14		
			15	BS.15		Bass 15	15		
			16				16		
					KCK2 (BANK16)				

Category	BANK Name	No.	Name	Note	Category	BANK Name	No.	Name	Note
SNARE	SNR1 (BANK17)	1	N.SNR	Normal Snare	HI HAT & CYMBAL	HH1 (BANK19)	1	NM.HH	Normal Hi Hat
		2	M.SNR	Melodic Snare			2	M.HAT	Metallic Hi Hat
		3	CLP.1	Dry Clap 1			3	CRSH	Crash Cymbal
		4	CLP.2	Dry Clap 2			4	SCRM	Metallic Scream
		5	H.SNR	Hard Snare			5	FHHF	FM Hi Hat
		6	SN.01	Snare 1			6	S.HH.1	Short Hi Hat 1
		7	SN.02	Snare 2			7	S.HH.2	Short Hi Hat 2
		8	SN.03	Snare 3			8	O.C.1	Open Close Hi Hat 1
		9	SN.04	Snare 4			9	O.C.2	Open Close Hi Hat 2
		10	SN.05	Snare 5			10	O.C.3	Open Close Hi Hat 3
		11	SN.06	Snare 6			11	HH.1	Hi Hat 1
		12	SN.07	Snare 7			12	HH.2	Hi Hat 2
		13	SN.08	Snare 8			13	HH.3	Hi Hat 1
		14	SN.09	Snare 9			14	HH.4	Hi Hat 1
		15	SN.10	Snare 10			15	HH.5	Hi Hat 1
		16	SN.11	Snare 11			16	HH.6	Hi Hat 1
		SNR2 (BANK18)	1	SN.12		Snare 12	1	M.RID	Metallic Ride
			2	SN.13		Snare 13	2	RID.1	Ride 1
			3	SN.14		Snare 14	3	RID.2	Ride 2
			4	SN.15		Snare 15	4	RID.3	Ride 3
			5	SN.16		Snare 16	5	RID.4	Ride 4
			6	SN.17		Snare 17	6	RID.5	Ride 5
			7	RIM.1		Rim Shot 1	7		
			8	RIM.2		Rim Shot 2	8		
			9				9		
			10				10		
			11				11		
			12				12		
			13				13		
			14				14		
			15				15		
			16				16		

Category	BANK Name	No.	Name	Note	Category	BANK Name	No.	Name	Note	
PERCUSSION	PRC1 (BANK21)	1	MLT.D	Multi Drum	BELL	BELL (BANK23)	1	CHIM	Chime	
		2	PIPE	PVC Pipes			2	BUNS	Bouncing Bell	
		3	CWB.1	Cowbell 1			3	BER3	Bell Release	
		4	CWB.2	Cowbell 2			4	LO.BL	LoBit Bell	
		5	TOM.1	Tom 1			5	HD.HT	Hardhit Bell	
		6	TOM.2	Tom 2			6	BEL.1	Bell 1	
		7	TOM.3	Tom 3			7	BEL.2	Bell 2	
		8	TOM.4	Tom 4			8	BEL.3	Bell 3	
		9	MRGB	Marimba			9	BEL.4	Bell 4	
		10	TMPN	Timpani			10	BEL.5	Bell 5	
		11	CNGA	Conga			11			
		12	BNG.1	Bongo 1			12			
		13	BNG.2	Bongo 2			13			
		14	BMBO	Bamboo			14			
		15	MTL.1	Metal1			15			
		16	MTL.2	Metal2			16			
		PRC2 (BANK22)	1	TECH	Techno Drum	CHORD	CHD1 (BANK24)	1	Q.MAJ	Square major
			2	CLK.1	Click 1			2	Q.MIN	Square minor
			3	CLK.2	Click 2			3	Q.MA7	Square M7
			4	CLK.3	Click 3			4	Q.MI7	Square m7
			5	CLK.4	Click 4			5	Q.7TH	Square 7
			6	CLK.5	Click 5			6	Q.AD9	Square add9
			7					7	Q.SU4	Square sus4
			8					8	Q.PWR	Square Power Chord
			9					9	W.MAJ	Saw major
			10					10	W.MIN	Saw minor
			11					11	W.MA7	Saw M7
			12					12	W.MI7	Saw m7
			13					13	W.7TH	Saw 7
			14					14	W.AD9	Saw add9
			15					15	W.SU4	Saw sus4
			16					16	W.PWR	Saw Power Chord

Category	BANK Name	No.	Name	Note	Category	BANK Name	No.	Name	Note
CHORD	CHD2 (BANK25)	1	S.MAJ	Strummed Major	SFX	SFX1 (BANK27)	1	ORRO	FM Riser
		2	S.MIN	Strummed Minor			2	CRWL	Crawl Noise
		3	S.MA7	Strum Major 7			3	FMJY	FM Jelly
		4	S.MI7	Strum Minor 7			4	IMHT	Industrial Hit
		5	S.7TH	Strummed 7			5	IDS3	Industrial SE
		6	S.AD9	Strummed add9			6	INDS	Industrial
		7	S.SU4	Strummed sus4			7	SQEK	The Squeak
		8	S.PWR	Strummed Power Chord			8	M3TE	Metal SE
		9	K.MAJ	Keys Major			9	TPDT	Tape Dust
		10	K.MIN	Keys Minor			10	F.WEB	Feedback Web 1
		11	K.MA7	Keys Major 7			11	RDFX	Broken Radio
		12	K.MI7	Keys Minor 7			12	FX.1	SFX 1
		13	K.7TH	Keys 7			13	FX.2	SFX 2
		14	K.AD9	Keys add9			14	FX.3	SFX 3
		15	K.SU4	Keys sus4			15	FX.4	SFX 4
		16	K.PWR	Keys Power Chord			16	FX.5	SFX 5
RHY THM	RYTM (BANK26)	1	CRYS	The Crystal	SFX	SFX2 (BANK28)	1	FX.6	SFX 6
		2	RW.AT	ReWind & Attack			2	FX.7	SFX 7
		3	REFL	Reflectica			3	FX.8	SFX 8
		4	S.MOD	Strings Modulation			4	FX.9	SFX 9
		5	TRON	Melotronica			5	FX.10	SFX 10
		6	MNML	Minimal Strings			6	FX.11	SFX 11
		7	RE.SN	ReAttack Sinewave			7	FX.12	SFX 12
		8	RE.BP	ReAttack Beep			8	FX.13	SFX 13
		9	R.YTM	The Rhythmica			9	FX.14	SFX 14
		10	RYT.M	The Rhythmica 2			10	W.NS.1	White Noise 1
		11					11	W.NS.2	White Noise 2
		12					12	W.NS.3	White Noise 3
		13					13	W.NS.4	White Noise 4
		14					14	W.NS.5	White Noise 5
		15					15		
		16					16		

Category	BANK Name	No.	Name	Note
XLFO	XLFO (BANK29)	1	DSQ1	Detuned Squares 1
		2	DSQ2	Detuned Squares 2
		3	DSW1	Detuned Saws 1
		4	DSW2	Detuned Saws 2
		5	DSN1	Detuned Sines
		6	PWM1	Pulse Width Modulation 1
		7	PWM2	Pulse Width Modulation 2
		8	ASW1	Acid Saw 1
		9	ASW2	Acid Saw 2
		10	ASQ1	Acid Square 1
		11	ASQ2	Acid Square 2
		12	PUL1	Pulse 1 (Narrow)
		13	PUL2	Pulse 2 (Wide)
		14	SHF1	Harmonic Shift 1
		15	SHF2	Harmonic Shift 2
		16	S.WEB	Soft Web

Authors



Chris Lody






Yasutake (elfin)





i-z-m-i



